



- ① Core drill openings at least 12 inches from existing manhole joints.
- ② Install flexible pipe coupler or pipe joint on new sanitary sewer 18 to 24 inches from outside of manhole wall.
- ③ Align elbow so discharge is directed at outlet pipe or at 45 degrees to manhole flow.
- ④ Reshape fillet to provide a smooth transition and to direct flow to outlet.

		REVISION
		New
FIGURE 6010.308 STANDARD ROAD PLAN		SW-308
DRAFT		SHEET 1 of 1
<i>Paul D. Weigand</i> PROJECT ENGINEER		<i>Scott Nide</i> METHODS ENGINEER
INTERNAL DROP CONNECTION FOR SANITARY SEWER MANHOLE		