



Tyler Ley, PE, PhD

Professor at Oklahoma State University for 13 y

Work experience with a contractor, DOT, and a consultant.

Research focus – Constructability, Durability, and Novel Test methods

YouTube Channel > 5M views and > 50K subscribers

## CONCRETE FREAK!!!!

1

Why Do You Lose Air Volume When  
Pumping Air-Entrained Concrete???  
*and Why Does the Air Come Back?*



Justin Becker, Nick Seader, Chad Staffileno  
Tyler Ley, PE, PhD,

2

### Acknowledgements

- Oklahoma DOT
- FHWA
- Colorado DOT
- Kansas DOT
- Nebraska DOT
- Iowa DOT
- Minnesota DOT
- Idaho DOT
- North Dakota DOT
- Pennsylvania DOT
- Connecticut DOT
- Illinois DOT
- Indiana DOT
- Michigan DOT
- Wisconsin DOT
- New Jersey DOT
- RMC Foundation
- American Concrete Pumping Association

### Acknowledgements

- Vermont DOT
- Jim Wild
- Justin LaRoche



5

## Overview

Why do we add air to concrete?

Why do pumps change the air content of concrete?

Why does the air come back?

If you see Pistol  
Pete then that  
means that  
something is very  
important!!!!



6


Why is this important?



8



9



10



11

Why is this happening?

12

## Why is this happening?

- Air void system
- Permeability – water to cement ratio
- Saturation level - environment

13

## Why is this happening?

- **Air void system**
- Permeability – water to cement ratio
- Saturation level - environment

14

## Why Do We Add Air to Concrete?


Air-entrained bubbles are a key to the freeze-thaw resistance of concrete

Air volume  $\neq$  freeze-thaw performance


Smaller bubbles are more effective in providing freeze-thaw resistance and have less of an impact on our concrete than larger bubbles

## What Do You Want in an Air-Void System?

A




B



- Volume of air provided is the same for both.
- Case B has a better air void distribution.



What Do You Want in an Air-Void System?



- Volume of air provided is the same for both.
- Case B has a better air void distribution.

AASHTO PP84

Freeze Thaw Field Acceptance

Air Volume  $\geq 4\%$

SAM Number  $\leq 0.30$



AASHTO PP84

Freeze Thaw Field Acceptance


Air Volume  $\geq 4\%$

SAM Number  $\leq 0.30$



Where is this from?




What air content do you use?



## What air content do you use?



## UNC Charlotte



## Discussion

The SAM Number can better predict freeze thaw performance than the air volume.

The SAM Number can be determined in fresh concrete in about 10 mins.

Why are we doing this?

Concrete pumps are essential tools in the industry but it is hard to predict how pumping will impact the air void system in concrete.

25

When you pump air entrained concrete one of three things will happen:

26

When you pump air entrained concrete one of three things will happen:

1. The air volume will go down

27

When you pump air entrained concrete one of three things will happen:

1. The air volume will go down
2. The air volume will go up

28

When you pump air entrained concrete one of three things will happen:

1. The air volume will go down
2. The air volume will go up
3. The air volume will stay the same

- Ken Hover

29

When you pump air entrained concrete one of three things will happen:

1. The air volume will go down
2. The air volume will go up
3. The air volume will stay the same

- Ken Hover

Engineers are worried about this and so it is common to require sampling after the concrete pump.

30



31



Concrete is delivered here

32





Concrete is  
sampled  
here

Concrete is  
delivered  
here

33



34

Ready Mix



General  
Contractor



35

Ready Mix

I brought you  
concrete with  
the right air!



General  
Contractor



36

Ready Mix

I brought you concrete with the right air!



General Contractor

It doesn't have the right air any more!!!




37

How do people deal with this?

Increase the air volume before it goes into the pump so that it still has enough air when it comes out.

One time this worked....

38



Durable asphalt

39

### Mechanisms

How does pumping change air?

1. Pressure



2. Vacuum



3. Impact



40

## Mechanisms

### How does pumping change air?

1. Pressure



2. Vacuum



3. Impact



41

## Methods

- Investigate the following before and after pumping:
- Air volume
- SAM Number (air void spacing) AASHTO TP 118
- Spacing factor (petrographic analysis) ASTM C 457
- Freeze-thaw performance ASTM C 666



## Mixture Design

- 0.45 w/cm
- 20% Class C ash
- 6.5 sacks (611 lbs)
- Limestone and natural sand
- 5" to 8" slump

Air contents from 4% to 8%


With and without water reducer/retarder

33 lab mixtures



44


## Pipe Network




45

## Lab Pumping Information

- 4" diameter pipe
- 60' of steel pipe
- 10' Rubber hose
- pumping pressures from 55 to 110 psi



47



48



## Summary



Before Pumping

33

Fresh Air > 4.0%  
SAM # < 0.32



After Pumping



Hardened Concrete

49

## Summary



Before Pumping

33

Fresh Air > 4.0%  
SAM # < 0.32



After Pumping

11

Fresh Air > 4.0%  
SAM # < 0.32



Fresh Air < 4.0%  
SAM # > 0.32

50

## Summary



Before Pumping

33

Fresh Air > 4.0%  
SAM # < 0.32



After Pumping

11

Fresh Air > 4.0%  
SAM # < 0.32



Fresh Air < 4.0%  
SAM # > 0.32

Hardened Concrete


33

ASTM C666  
Durability Factor > 70%




51


## A Clue!!!



52



53



54

## Discussion

- Satisfactory freeze thaw performance of pumped concrete was observed even though there were low air contents and high SAM Numbers after pumping.
- BUT! There is minimal change in the spacing factor measured on the hardened concrete taken before and after pumping.

55

## Discussion


- The hardened and fresh measurements closely matched prior to pumping.
- After pumping the hardened air content was on average 1.15x higher in the fresh air content.

For example – After pumping 6% fresh and about 7% in hardened concrete

**The fresh measurements after pumping do not represent the performance or properties of the hardened concrete.**

56

Reliable Unreliable Reliable



57

Does this hold for other equipment and mixtures?

58

## Field Pumping Information

- 62 different mixtures tested
- 30+ different projects
- Bridge decks, walls, sidewalk, parking lot, drilled shaft
- 18 Different Types of Pumps
- Boom lengths ranged from 100' to 180'
- Pipes from 4" to 6" in diameter
- Used three different boom configurations

Flat



Arch




A-Frame



60

## Pump configurations




Flat


Arch

A-frame


61



62



63




64



### 29% Increase

- 32% A-Frame
- 44% Arch
- 40% Flat




65

## Discussion


- Air Content
  - 24% of samples show a significant decrease
  - A-frame caused the most impact on the air volume after pumping
- SAM Number
  - 29% of samples increased significantly
  - Arch configuration caused the most impact on void spacing after pumping

66


How about the hardened concrete?




67




68



69



70



71

## Discussion

- The hardened and fresh measurements closely matched prior to pumping.
  - After pumping the hardened air content was on average 1.15x higher than the fresh air content.
- For example – After pumping 6% fresh and about 7% in hardened concrete
- There is no significant change in the spacing factor when comparing data before and after pumping.

72

## Discussion

These are the same findings from the lab but with different pump configurations, equipment, and materials!!!!

**The fresh measurements after pumping do not seem to represent the performance or properties of the hardened concrete.**


73

## What is happening?


74

Where does the air change within the pump network?

75



76



77

## Discussion

The air is lost right after the pump and stays almost constant throughout the pipe network.

Additional piston strokes (pressure cycles) did not cause additional air to be lost.

The Air loss coincides with point of highest pressure.

78

### Why does this happen?

Henry's Law –  $p = kc$

$p$  = partial pressure of the gas

$c$  = concentration of the dissolved gas in solution

$k$  = constant

↑ Pressure




↑ Dissolved gas





79

### How does this change the bubble size distribution?





80














## Discussion

1. As the pressure increases the small bubbles dissolve into the surrounding solution
2. These bubbles do not immediately come back when you decrease the pressure.


94

## Why do the small bubbles dissolve???

### Laplace-Young Equation


$$P_i = P_o + 4\sigma/d$$

- $P_i$  = internal pressure of the air bubble
- $P_o$  = pressure of fluid surrounding the bubble
- $\sigma$  = surface tension of the bubble film
- $d$  = bubble radius



95

## Why do the small bubbles dissolve???




- As you increase the pressure, air will dissolve in the surrounding solution (Henry's Law)
- Because the smaller bubbles are at a higher pressure they dissolve before the larger bubbles

## What does this mean?

- The pressures during pumping causes the small bubbles to dissolve and so they are not present in the fresh concrete when it discharges from the pump.
- This is why the air volume decreases and the SAM Number increases.

97



98

## Air and SAM over time

- We pumped concrete and measured how the air volume and SAM Number change over time.




Sampling time  
after pumping

15 min


30 min

45 min

99




100




101

Bubbles  
go away


Bubbles  
come back?



102



103




104



Bubble  
spacing  
increases

Bubble  
spacing  
decreases?



105


## What is happening???

- The pressures from pumping causes the small bubbles to **temporarily** dissolve
- But good performance in the petrographic analysis, freeze-thaw testing, and reducing SAM Number over time suggests that the **dissolved air comes back before the concrete hardens.**
- When the air comes back it seems to be well dispersed and provides a similar spacing factor to what went into the pump.

106



107



108



109



110



111

What does this mean?

- **Air Content and SAM testing after pumping are not representative of the hardened concrete.**
- If this is true then concrete should not be rejected for low air or high SAM Number after pumping.
- It appears that sampling the concrete prior to pumping is a good indicator to the air void system in the hardened concrete.

112

## What do I think needs to happen?

- Testing air at the point of discharge from a pump is dangerous and it is not representative of the properties of the hardened concrete.
- We need to test concrete before pumping and not require testing at the point of placement.

113

## What do I think needs to happen?

- I think our air testing needs to be done with the SAM because it better correlates with freeze thaw performance.
- We need to have local discussions about how we need to change specifications and construction practices.

114

## Integrating Construction Practices and Weather Into Freeze Thaw Specifications [TPF-5(448)]

Idaho	North Dakota
Iowa	<b>Oklahoma</b>
Kansas	Pennsylvania
Minnesota	Wisconsin
Missouri	FHWA
New York	American Concrete Pumping Association

115

## Integrating Construction Practices and Weather Into Freeze Thaw Specifications [TPF-5(448)]

Idaho	North Dakota
Iowa	<b>Oklahoma</b>
Kansas	Pennsylvania
Minnesota	Wisconsin
Missouri	FHWA
New York	American Concrete Pumping Association

**Join Now!!!**

116





117



118



119

Ready Mix

I brought you  
concrete with  
the right air!



General  
Contractor



120

Ready Mix

I brought you  
concrete with  
the right air!



General  
Contractor

YAY!!!  
I love you.



121



122

## Conclusion

- Pumping was observed to modify the air content and SAM Number in both the lab and the field testing.
- Based on the hardened air void analysis, freeze thaw testing, and changing SAM Number over time, the small bubbles seem to return to the concrete with a similar air void distribution and freeze thaw performance as was in the concrete before pumping.
- The SAM was an invaluable tool to give insights into the performance of air before and after a concrete pump.

123

[www.youtube.com/tylerley](http://www.youtube.com/tylerley)



TYLER LEY, PE, PHD



Questions?

[www.tylerley.com](http://www.tylerley.com)

[Tyler.ley@okstate.edu](mailto:Tyler.ley@okstate.edu)

Join **TPF-5(448)**